POWER PACKS AND LINEAR DRIVES FOR AUTOPILOTS



20 19

Lecomble & Schmitt s.A.s.

BP N° 2 64240 URT – France

Sales Department: 33 (0) 559 56 24 11 - commercial@ls-france.com Technical Department: 33 (0) 559 56 26 46 - commercial2@ls-france.com Fax : 33 (0) 559 56 95 71

http://www.ls-france.com

CONTENTS

		Pages
•	Introduction – Description	2
•	Working Principle	3
•	Selection of the System	4
•	Different Types of Installations	5
•	Power packs for Motorboats or Sailing Boats Equipped with Hydraulic Steering	
	 Reversible Power Packs 	6
	 Power packs with Electrovalves 	7
•	Hydraulic Linear Drives for Sailing Boats Equipped with Mechanical Steering	
	 Internal Installation with fixed flow 	8 & 9
	 Internal Installation with adjustable flow 	10
	 External Installation (cylinder only) with fixed flow 	11
•	Accessories	12
•	Hydraulic Flexible Tubes	13
•	Fittings	14
•	Connection Kits for Raymarine and Garmin Autopilots with LS Outboard Steering Systems	15
•	Notes	

• Guarantee

INTRODUCTION

LS power packs and linear drives for autopilots are perfectly adapted to the requirements of different applications, such as pleasure boating, workboats, professional or amateur fishing, competition and its accompaniment.

They are easy to install, state of the art machine finished and made to resist a marine environment.

You can easily select the best suited system for your boat within the most comprehensive range available on the market with a guarantee of efficiency, reliability and security.

Our systems carry a 2 year warranty and are **CE** approved. They are fully compatible with all brands of autopilots on the market today.

DESCRIPTION OF HYDRAULIC POWER PACKS AND LINEAR DRIVES FOR AUTOPILOTS

As a general rule, the basic set up of a hydraulic system for autopilot consists of:

- 1 hydraulic cylinder,
- 1 hydraulic power pack,
- Fittings and tubing to connect the cylinder to the power pack.

Other elements will be added to this basic set up in function of the configuration of the boat steering system – hydraulic steering, wire ropes, cables, etc.

Cylinder

The cylinder is the dictating element in the selection of a system. It gives the pushing power to the steering system in function of its effective area and the pressure it receives from the power pack. To select the cylinder, follow the method given in paragraph "Selection of the System".

Hydraulic Power Pack

Power packs are always composed of a reversible or non reversible electrical motor in 12 or 24 volts DC, or 220/240 V single-phased or three-phase, coupled to a reversible or non reversible axial piston pump or gear pump, with adjustable or fixed flow rate.

Receiving orders from the electronics, the power pack will suck or force back the oil in the circuit. The speed of correction is determined in function of the pump flow rate in litres per minute.

Our systems are fitted with lock valves which prevent cylinder movements once the boat is on the desired course until a new course correction is required.

They are also fitted with pressure relief systems to protect the circuit against abnormal pressure increases.

Tubing


Tubing is designed for hydraulic oil transfer under pressure. Tubing diameter is selected in function of the power pack flow rate.

WORKING PRINCIPLE

When the boat moves away from the displayed course, the autopilot electronic computer sends current to the motor terminals or to the power pack electrovalve. Then, the cylinder will be supplied with oil and set in motion. As soon as the boat is back on the displayed course, the computer stops supplying the power pack and the cylinder stops moving.

• MOTORBOATS EQUIPPED WITH HYDRAULIC STEERING

- $\textcircled{1} \quad \text{Manual pump} \quad$
- $\textcircled{2} \ \text{Tubing}$
- 3 Power pack
- ④ By-pass valve
- 5 Cylinder
- 6 Tiller arm



SAILING BOATS EQUIPPED WITH WIRE ROPE STEERING

- ① Manual steering
- 2 Quadrant
- ③ Linear cylinder
- ④ Rudder stock
- (5) Wire rope
- 6 Power pack



SELECTION OF THE SYSTEM

• For boats equipped with a hydraulic steering, it will be necessary to determine: - The volume of the steering cylinder (take the biggest volume in case of a single rod cylinder) - Available voltage on board (12 VDC, 24 VDC, etc.)

For planing or semi-planing hulls, the power pack will be selected in function of its flow rate so that the steering cylinder will run its complete stroke within 10 to 12 seconds.

For displacement hulls, the power pack flow rate must enable the steering cylinder to run its complete stroke within 15 to 17 seconds.

Examples

Speed boat, planing hull with a 239 cc cylinder – Available voltage 12 VDC

60 seconds (1 minute) x 0.239 litre (239 cc) = 1.195 litre / minute

12 seconds (required time)

The flow rate of the required power pack will be 1.19 litre / minute, therefore we will select a reversible power pack with adjustable flow rate type RV2 (12 V) - page 6

Eishing or work boat, displacement hull with a 2,307 cc cylinder – Available voltage 24 VDC

60 seconds (1 minute) - x 2.307 litres (2,307 cc) = 9.228 litres / minute

15 seconds (required time)

The flow rate of the required power pack will be around 9 litres / minute, therefore we will select a power pack type HF 1.5 – 9 (24 V) – page 7


• For boats equipped with a mechanical steering (wire ropes, cables, rack and pinion), it will be necessary to determine:

The rudder(s) torque


- The available voltage on board (12 VDC, 24 VDC, etc.)

Torque Calculation:

For boats fitted with a rudder with speed not exceeding 25 knots, the torque (C) of the rudder or rudders will be calculated according to the formula and correction coefficients below: Lg



Length not exceeding 33 feet Length not exceeding 44 feet Length not exceeding 60 feetLinear drive type 32ST16 NEWAVE* Linear drive type 40ST16 NEWAVE * Linear drive type 50ST20 NEWAVE * Linear drive type 63ST28 DEBP NEWAVE *page 8 page 8 page 8 page 9Length not exceeding 80 feetLinear drive type 63ST28 DEBP NEWAVE * Linear drive type 63ST28 DEBP NEWAVE * DEBP NEWAVE *page 8 page 8 page 9 (*) Data given as an indication of (*) Data given as an indication of (*) Data given as an indication of



POWER PACKS FOR MOTORBOATS OR SAILING BOATS EQUIPPED WITH HYDRAULIC STEERING

REVERSIBLE POWER PACKS FOR DOUBLE ROD CYLINDERS


Hydraulic power packs with adjustable flow in 12 or 24 V for pleasure, fishing and work boats. They are reversible by changing the polarity on the motor terminals. Flow adjustment is done through a screw which allows accurate regulation of the time required for lock to lock displacement. These power packs are fitted with lock valves.


REVERSIBLE POWER PACKS FOR SINGLE ROD CYLINDERS

Hydraulic power packs with adjustable flow in 12 or 24 V for pleasure, fishing and work boats fitted with a single rod cylinder (unbalanced cylinder on outboard or stern-drive motors). They are reversible by changing the polarity on the motor terminals. Flow adjustment is done through a screw which allows accurate regulation of the time required for lock to lock displacement. These power packs are fitted with lock valves.

	12 VOLTS	24 VOLTS
R V 1	2200843	2200944
R V 2	2200410	2200945
R V 3	2200403	2200946

	12 VOLTS	24 VOLTS
R V 2-Z	2203240	2203261
R V 2-2	2203240	2203261






POWER PACKS FOR MOTORBOATS OR SAILING BOATS EQUIPPED WITH HYDRAULIC STEERING

POWER PACKS WITH ELECTROVALVES

Hydraulic power packs with adjustable flow in 12 or 24 V for pleasure, fishing and work boats. They are fitted with an electrodistributor and an oil reservoir. Flow adjustment is done through a screw which allows accurate regulation of the time required for lock to lock displacement.

Type of power pack	EV2	EV3
Maximum cylinder capacity (cc)	432	650
Power pack flow rate (I/mn)	0.2 à 2	0.3 à 3
Oil reservoir capacity	1 L	1 L
Recommended protection 12/24 V	25 A / 16 A	30 A / 16 A




HF 1-2.5 – HF 1-3 – HF 1-4 HF 1-6 – HF 1.9-9 – HF 1.9-11 HF 3-15 – HF 3-18

Hydraulic H.F. units are mainly designed for large pleasure boats, fishing and work crafts.

Owing to a very strong construction, large oil tanks, high reliability of the pumps and distributors and to the easily accessible external mounting of elements connected with flexible tubes, these devices are the leaders on the market in the field of hydraulic electro-pump units.

			-	-	-	-			
Type Tank code volume		Flowrate weight	A	в	с	D			
HF 1-2.5			750	460	220	125			
2200190			29 ¹⁷ /32	18 ⁷ /64	8 ⁵ /8	4 ⁵⁹ /64			
HF 1-3	10 1100		750	460	220	125			
2200148			29 ¹⁷ /32	18 ⁷ /64	8 ⁵ /8	4 ⁵⁹ /64			
HF 1-4	10 litres	4 l/mn	750	460	220	125			
2200149	2.65 US.gall	35 kg	29 ¹⁷ /32	18 ⁷ /64	8 ⁵ /8	4 ⁵⁹ /64			
HF 1-6 25 litres 2200150 6.62 US.gall HF 1.9-9 25 litres 2200151 6.62 US.gall		6 l/mn 45 kg	750 29 ¹⁷ /32	560 22 ³ /64	270 10 ⁵ /8	225 8 ⁷ /8			
		9 l/mn 57 kg	750 29 ¹⁷ /32	560 22 ³ /64	270 10 ⁵ /8	225 8 ⁷ /8			
HF 1.9-11	25 litres	11 l/mn	770	560	270	225			
2200195	6.62 US.gall	57 kg	30 ⁵ /16	22 ³ /64	10 ⁵ /8	8 ⁷ /8			
HF 3-15	50 litres	15 l/mn	810	785	270	450			
2200955	13.2 US.gall	61 kg	31 ⁵⁷ /64	30 ²⁹ /32	10 ⁵ /8	17 ³ /8			
HF 3-18	50 litres	18 l/mn	810	785	270	450			
2200562	13.2 US.gall	62 kg	31 ⁵⁷ /64	30 ²⁹ /32	10 ⁵ /8	17 ³ /8			
Nota	60 bars maximum pressure Nota : Standard 24 VDC. Other voltages upon request								








2203064


- Compact overall dimensions.
- Directly fitted on the quadrant.
- Possible floor, ceiling or bulkhead installation of the cylinder.
- Separate reversible power pack with fixed flow for installation at your selected location.
- The kit is supplied assembled and bled with 1.20 metre flexible tube (Other lengths on request).
- Features the best thrust/electrical consumption ratio on the market.
- Available with LHM high performance oil (on request)

A 2203066	Linear drive 40ST16 NEWAVE 12V RI					
A 2203067	Linear drive 40ST16 NEWAVE 24V RI					
2203068 Linear drive 50ST20 NEWAVE 12V RI						
2203069	Linear drive 50ST20 NEWAVE 24V RI					
2203070 Linear drive 50ST203 NEWAVE 12V RI						
2203071 Linear drive 50ST203 NEWAVE 24V RI						
f A For steering wheel diameters exceeding 1200 mm and for B&G and Simrad						

Linear drive 32ST16 NEWAVE 24V RI

▲ For steering wheel diameters exceeding 1200 mm and for B&G and Simrad autopilots, we recommend that linear drives with adjustable flow on the reversible power packs be used (see page 10).





2203077	RV1 NEW RV2 NEW RV3 NEW	AVE 12V	2203078	RV1 NEWA RV2 NEWA RV3 NEWA	VE 24V
A B C		D	F		
80 3 ⁵/32	70 2 ³ /4	206 7 ⁷ /64	4	24 _ ¹⁵ /16	280 11 ¹ /64

Øc	TYPE	VHM 32S	VHM 32ST16 NEWAVE		VHM 40ST16 NEWAVE		VHM 50ST20 NEWAVE			
φc	Code 12V	2203084		2203086		2203088				
4	Code 24V	2203085		22	03087	2203089				
14 (⁹ /16)	Maximum thrust	280 kg	617 lbs	450 kg	992 lbs	700 kg	1543 lbs			
(~/16)	Weight	3,5 kg	7.71 lbs	3,5 kg	7.71 lbs	5 kg	11 lbs			
	Α	120 mm	4 ²³ /32	120 mm	4 ²³ /32	120 mm	4 ²³ /32			
	В	563 mm	22 ¹¹ /64	613 mm	24 ¹ /8	715 mm	28 ⁹ /64			
	С	15 mm	_ ^{19/} 32	15 mm	_ ^{19/} 32	17 mm	_ ^{43/64}			
	D	46 mm	1 ¹³ /16	56 mm	2 ⁵⁵ /64	70 mm	2 ³ /4			
ŹĖ	E	210 mm	8 ¹⁷ /64	240 mm	9 ⁷ /16	300 mm	11 ¹³ /16			
	F	170 mm	6 ¹¹ /16	190 mm	7 ³¹ /64	240 mm	9 ²⁹ /64			
	G	160 mm	6 ¹⁹ /64	172 mm	6 ⁶¹ /64	218 mm	8 ³⁷ /64			
	9		0 10/04	172 11111	0 * /04	210 1111	0 * /04			




- Features the best thrust/electrical consumption ratio on the market.
- Available with LHM high performance oil (on request)

Dx∅ A

©€

1/4 BSPP	1/4 BSPP	220308	0 RV3 NEV	VAVE 12V	220308	1 RV3 NEW	AVE 24V
		Α	В	С	D	Е	F
26,5		80	70	206	4	24	280
A	+ + + +	3 ⁵/32	2 ³ /4	8 ⁷ /64		_ ¹⁵ /16	11 ¹ /64



	• ••-		• • • •				
	TYPE		VH	M 63ST28 DEBI	P NEWAVE		
	Code 12	v		220380	6		
	Code 24	v		220380	3		
	Maximum th	irust	1	110 kg	2447 lbs		
	Weight		18 kg 39.65 lbs		39.65 lbs		
	Α		180 mm 7 ³ / 32		7 ³/ 32		
	В	B 802 mm 31 ³⁷ /64		31 ³⁷ /64			
Ŧ	C		C 25 mm _ ⁶³ /64		_ ⁶³ / 64		
D		9	0 mm	3 ³⁵ /64			
	E		3	00 mm	11 ¹³ /16		
-	F		2	40 mm	9 ²⁹ /64		
	G		2	18 mm	8 ³⁷ /64		



- Speed adjustment on the reversible power pack.
- Separate reversible power pack with adjustable flow for installation at your selected location.
- The kit is supplied assembled and bled with 1.20 metre flexible tube*.
- All fittings in stainless steel.

* Other lengths on request.

G1/4 (DRAIN)	2201100	RV2 - S ⁻	T - 12V	22	01101 F	RV2 - ST -	24V
		Α	В	С	D	Е	F
	RV2 - ST	80 3 ⁵/32	70 2 ³/4	206 7 ⁷ /64	4	24 _ ¹⁵ /16	280 11 ¹ /64

	TYPE	VHM 40ST16 NEWAVE
$G1/4$ ϕ D $-\phi$ C	Code 12V	2203086
	Code 24V	2203087
A 71 (2 ⁵¹ /64) 14	Maximum thrust	450 kg 992 lbs
B (⁹ /16) (4 ³ /8)	Weight	3,5 kg 7.71 lbs
<u>⊦</u> □110	А	120 mm 4 ²³ /32
$\begin{array}{c c c c c c c c c c c c c c c c c c c $	В	613 mm 24 ¹ /8
	с	15 mm - ¹⁹ /32
	D	56 mm 2 ⁵⁵ /64
G $4x \not = 0.5 (27/64)$	E	240 mm 9 ⁷ /16
ļ <u></u>	F	190 mm 7 ³¹ /64
	G	172 mm 6 ⁶¹ /64




electrical by-pass, for installation at your selected location inside the boat.

- The kit is supplied assembled and bled with 1.50 metre flexible tube*.
- Available with LHM high performance oil (on request)

2203065	Linear drive 32ST16BP NEWAVE 12 V
2203073	Linear drive 40T254BP NEWAVE 12 V Elbow fittings on cylinder

* Other lengths on request.



					• VHM 32 ST • VHM 40 T (
CODE	ТҮРЕ	Α	В	С	D	E	F	Thrust
2201261	VHM 32 ST 16 C172	136.5	482	172	150	15	16	280 kg
2201960	VHM 40 T C254	200	609	254	220	17	20	450 kg

LINEAR DRIVES ACCESSORIES

2200017 2 Litre Oil Can Dexron II

2202047









2201558

QUICK COUPLINGS

Ø 15 Quick Coupling in S/steel

in S/steel

Ø 17 Quick Coupling





ENERGY SAVING DEVICE "ECOPILOT"

The "Ecopilot" energy saving device was designed to meet the demand for electrical energy saving on sailing-boats. Power reserve on board is often very limited, however it is essential for the operation of an autopilot system.

The "Ecopilot" acts on the electro-valve which engages the autopilot. The power consumption of this electro-valve represents a major part of the total autopilot consumption.

Its action consists of letting through - during a short moment - the necessary current for the electro-valve to switch on. Then the current is significantly reduced but still sufficient to maintain the electro-valve in position.

Thanks to this system, the daily consumption of the electro-valve is reduced in average from 30Ah to 5Ah.

2202047 ECOPILOT 12 V 2202048 ECOPILOT 24 V	
Power supply Own Consumption Output current at switching (I _e)	0.01A
Output current after switching Switching time Protection Power supply indicator Working temperature	0.2s IP65 LED yellow

ECODIL OT 42 V



MAINTENANCE KITS FOR LINEAR DRIVES 2202457 Maintenance kit for linear drives standard and Newave 32ST16 / 40ST16 - 12 V 2202459 Maintenance kit for linear drives standard and Newave 32ST16 / 40ST16 - 24 V 2202458 Maintenance kit for linear drives standard and Newave 40T254 / 50ST20 - 12 V 2202460 Maintenance kit for linear drives standard and Newave 40T254 / 50ST20 - 24 V Maintenance kit composition Code Electro-hydraulic clutch 12 V 1202453 Electro-hydraulic clutch 24 V 1202454 Swivel yoke Ø 15 1200387 Swivel yoke Ø 17 1200436 Brush holder + Brushes 1200904 All types RV1 – RV2 Simple, handy, compact (Weight = 950 g)

FLEXIBLE TUBES FOR CRIMP CONNECTIONS

Only the sole use of LS flexible tubes in Ø6, Ø8 or Ø10 mm will guarantee the global performances of LS steering systems.

A few references:

 Ø6 Flexible tube - per metre Ø8 Flexible tube - per metre Ø10 Flexible tube - per metre 	2200810 2200024 2200070	
 Ø6 Flexible tube - length 8 m Ø6 Flexible tube - length 10 m Ø6 Flexible tube - length 12 m 	1204267 1204268 1204740	
 Ø6 Flexible tube - length 25 m Ø6 Flexible tube - length 35 m Ø6 Flexible tube - length 400 m 	1204985 1205301 1205359	
 Ø8 Flexible tube - length 10 m Ø8 Flexible tube - length 12 m Ø8 Flexible tube - length 20 m 	1204825 1204742 1205245	
 Ø8 Flexible tube - length 20 m Ø8 Flexible tube - length 35 m Ø8 Flexible tube - length 400 m 	1205245 1205300 1205360	

FLEXIBLE TUBES WITH PRE-CRIMPED CONNECTIONS

High pressure flexible tubes of various lengths with pre-crimped connections of various kinds (several diameters, straight fittings, 90° elbow fittings). Stainless steel fittings available.

1290385

1290378

A few references in 10 L :

 Flex. tube R1T8 lg 500 – 2 x EFT10L 	1290013
 Flex. tube R1T8 lg 1000 – 2 x EFT10L 	1290023
- Flex. tube R1T8 lg 1500 – 2 x EFT10L	1290025
- Flex. tube R1T8 lg 2000 – 2 x EFT10L	1290027
 Flex. tube R1T8 lg 3000 – 2 x EFT10L 	1290117

A few references in 12 L :

 Flex. tube R1T10 lg 500 – 2 x EFT12L 	1290042
- Flex. tube R1T10 lg 1000 – 2 x EFT12L	1290052

- Flex. tube R1T10 lg 1000 2 x EFT12L 1290052
 Flex. tube R1T10 lg 1500 2 x EFT12L 1290054
- Flex. tube R1T10 lg 2000 2 x EFT12L 1290056
- Flexi. tube R1T10 lg 3000 2 x EFT12L 1290130

A few references in 15 L :

- Flex. tube R1T13 lg 500 2 x EFT15L
- Flex. tube R1T13 lg 1000 2 x EFT15L 1290376
- Flex. tube R1T13 lg 2000 2 x EFT15L 1290387
- Flex. tube R1T13 lg 2500 2 x EFT15L

A few references in 18 L :

- Flex. tube R1T16 lg 500 2 x EFT18L 1290077
- Flex. tube R1T16 lg 1000 2 x EFT18L 1290087
- Flex. tube R1T16 lg 1500 2 x EFT18L 1290089
- Flex. tube R1T16 lg 2000 2 x EFT18L 1290091
- Flex. tube R1T16 lg 3000 2 x EFT18L 1290112

Other lengths on request. Possibility to make up specific kits as needed.

FITTINGS

FOR FLEXIBLE TUBE

Ту	ре	Designation	Code for steel	Code for s/steel
	Elbow fittings 90°	1/4 BSPT JIC M. 9/16	2200321	2200309
U		3/8 BSPT JIC M. 9/16	2200426	
	Swivel elbow fitt.	1/4 BSPP JIC M. 9/16	1205997	1206365
	Swivel elbow fitt.	JIC M. 9/16 – JIC F 9/16	1205894	1205656
	Straight fittings	1/4 BSPT JIC M. 9/16	2200427	2200447
53		1/4 BSPP JIC M. 9/16	2200199	2200448
		3/8 BSPT JIC M. 9/16	2200428	
U		3/8 BSPP JIC M. 9/16	2200429	2202039
	Adapters	1/4 BSPT JIC F.T. 9/16	2200430	
	-	3/8 BSPT JIC F.T. 9/16	2200356	
	Connection fitt.	JIC M. 9/16	2200288	
	Tee fittings	1/4 BSPT 2 x JIC M. 9/16	2200431	1203946
A CAD	-	3/8 BSPT 2 x JIC M. 9/16	2200432	
	Equal tee fittings	JIC M. 9/16	2200433	2202009
	Swivel tee fittings	Rotatable JIC M. 9/16	2201566	
No. of Concession, Name	Straight fittings	JIC M. 9/16 inner diam. 8	2200299	2200449
-		JIC M. 9/16 inner diam. 10	2200301	
	Elbow fittings	Inner diam. 8	2200302	
	-	Inner diam. 10	2200303	
	Connection fitt.	Inner diam. 8	2200373	
		Inner diam. 10	2200434	

FOR INFLEXIBLE TUBE

	Straight fittings	1/4 BSPP diam. 8	2200435	
	et et gette state gette	1/4 BSPP diam. 10	2200436	
and a second second		3/8 BSPP diam. 10	2200437	
****** P2 C+++		3/8 BSPP diam. 12	2200438	
		3/8 BSPP diam. 15	1203905	1205517
		1/2 BSPP diam. 18	2200439	
	Elbow fittings	1/4 BSPT diam. 10	2200440	
		3/8 BSPT diam. 12	2200306	
		3/8 BSPT diam. 15	1204618	
		1/2 BSPT diam. 18	2200441	
	Tee fittings	1/4 BSPT diam. 10	2200442	
		3/8 BSPT diam. 12	2200443	
		1/2 BSPT diam. 18	2200339	
	Connection fitt.	Diam. 10	2200469	
		Diam. 12	2200585	
···-·		Diam. 15	1206228	1205518
		Diam. 18	2200270	
	Equal tee fittings	Diam. 8	2200444	
		Diam. 10	2200259	
		Diam. 12	2200445	
		Diam. 15	1204627	1206521
		Diam. 18	2200446	
	Swivel tee fittings	Diam. 10	1204516	
()) - () - () () () () () () () () () () () () ()	-	Diam. 12	1202634	
		Diam. 18	1202635	
<u> </u>	Reductions	1/8 BSPP M – 1/4 BSPP F	1202438	
		1/4 BSPP M – 3/8 BSPP F	2200390	1206522
		1/4 BSPP M – 1/2 BSPP F	2200389	2200859
and a statement		3/8 BSPP M – 1/4 BSPP F	2200374	1203268
		3/8 BSPP M – 1/2 BSPP F	2200396	2200858
		1/2 BSPP M – 1/4 BSPP F	2200221	
		1/2 BSPP M – 3/8 BSPP F	2200332	

CONNECTION KITS FOR RAYMARINE, SIMRAD AND GARMIN AUTOPILOTS WITH LS OUTBOARD STEERING SYSTEMS Γ

Designation	Code	Designation	Code
RAYMARINE / SIMRAD Connection kit S1000 - Ø6 220248		RAYMARINE / SIMRAD Connection kit S1000 - Ø8 REC	2202483
RAYMARINE / SIMRAD Connection kit S1000 - Ø8	2202482	GARMIN Connection kit (before 02/2018) - Ø8 REC	2203007
GARMIN Connection kit (before 02/2018) - Ø6 2203005		GARMIN Connection kit (after 02/2018) - Ø8 REC	2203832
GARMIN Connection kit (before 02/2018) - Ø8	2203006		

LS Outboard Steering	Ø 6 Flex. Tube for crimping (collar)			. Tube for g (collar)		ube reusable ngs	
	RAYMARINE / SIMRAD Connection kit	GARMIN Connection kit	RAYMARINE / SIMRAD Connection kit	GARMIN Connection kit	RAYMARINE / SIMRAD Connection kit	GARMIN Connection kit	
LS 2024	2202481*	2203005*					
LS 226	2202481*	2203005*					
LS 2428	2202481*	2203005*					
LS 75 PRO / 80 PRO	2202481*	2203005*					N V
LS 125 PRO / 150 PRO	2202481*	2203005*					
LS 228					2202483	2203007 2203832	
1 6 2922 / 200 000			2202492*	2202006*	2202402	2203007	
LS 2832 / 200 PRO			2202482*	2203006*	2202483	2203832	
LS 175 PRO / 225 PRO			2202482*	2203006*	2202483	2203007	
ES 173 FRO 7 223 FRO			2202402	2203000	2202403	2203832	
LS 232					2202483	2203007	
					2202400	2203832	
LS 350 PRO / 3500 PRO					2202483	2203007	Each kit is sup
					2202400	2203832	8 m flexibl




pplied with le tube



- For do	uble steering station, add to the standard kit: Designation	Code
Õ	Tee fitting for flex. tube Ø 6	2202498
	Tee fitting for flex. tube Ø 8	2202499

NOTES



GUARANTEE

1) The manufacturer guarantees the equipment sold and supplied against any faulty manufacturing or defects whether they are the result of the design, the TaW material, the manufacturing or construction under the terms and restrictions indicated below :

2) The guarantee is applicable only if the client has satisfied the general obligations of this contract, in particular, the terms of payment.

3) The guarantee only includes equipment sold by the manufacturer. It does not extend to equipment in which the manufacturers supply has been installed and, in particular, to the performances of this equipment.

4) When the manufacturers supplies are installed by the client or a third party into any other equipment, they remain solely responsible for this installation, the selection and suitability of the manufacturers supplies as the manufacturers diagrams, designs and proposais are given as an indication only, unless otherwise specified in the order. In particular, the manufacturer does not guarantee components or equipment not sold by him, nor the assembly, adaptation, design or operation of the assembly or parts of the assembly thus created. The manufacturers supply, as well as the assembly created by the client or a third party, are assumed to be operated under the exclusive control of the client or the third party.

5) The period of the guarantee is eighteen months starting from the date of first use by the original consumer or twenty four months from the date of delivery of the products to the transporter, distributor or wholesaler. The manufacturer has the right to require from the client proof of the commissioning date specified on the guarantee request. This period is neither extended nor interrupted through legal or amicable claims on the part of the client. At the end of this period, the guarantee is terminated without further consideration.

6) The obligation of the guarantee only applies if the client establishes that the defect appeared under normal operating conditions stipulated for this type of supply, or indicated by the manufacturer in writing and during normal operation. It does not apply in case of negligence, faulty maintenance or supervision, operators responsibility, imprudence, non observance of recommended or operating instructions, or the use of oil of insufficient quality for the equipment. The manufacturer is released from responsibility for any damage caused by loss of oil or leaks. The guarantee also does not apply for any incidents resulting from a case of force majeure or Acts of God, as well as any damage, replacement or repairs exceeding the normal material wear.

7) The guarantee is limited to the repair in the manufacturer's shop at his own cost within the shortest possible time, of the equipment and parts supplied by him, identified as defective by the technical department. These parts must be sent pre-paid. No claim may be made for compensation for any damage such as personal injury, damage to goods other than those concerned in this contract, privation of possession, operating losses, commercial damage or loss of earnings. During the guarantee period, the cast of labor, dismantling and reassembly of the equipment outside the manufacturer's plant, the shipping costs for repaired, replaced or faulty equipment, travelling and accommodation expanses for technicians are the responsibility of the client.

When the guarantees are given according to the industrial results for a given equipment, these results and the consequences of this undertaking will result in a special agreement between the parties.

8) In order to take advantage of this guarantee, the client must notify the manufacturer in writing as soon as possible of the defects attributed to the equipment and provide any proof concerning these defects. He must do his best for the manufacturer to be able to ascertain these defects and to perform corrective actions. The guarantee does not apply if the equipment is not returned to the manufacturer in the state in which it broke down or if it has previously been disassembled, repaired, modified either by a third party, the user or the client. After receiving proper notification of the equipment defect, the manufacturer shall correct this fault as soon as possible, reserving the right, if applicable, to modify all or part of equipment in order to fulfil the obligations.

9) The client agrees that the manufacturer will not be responsible for damage due to the fact that the client has not satisfied anyone of the obligations defined above.

